
## AKO Three-Way Temperature Regulator Type Series 226.0121 with manual override deliverable sizes: 40, 50, 65, 80, 100, 125, 150 mm



## Installation:

FI

The installation can be done selectively as follows:as divideras mixing valvepath A:from motorpath C: from coolerpath B:to bypasspath B: from bypasspath C:to coolerpath A: to motorThe pathes have been marked on the connections.mperature regulator may be installed in all positions.

## **Technical Data**

Material: - Body - Inner Parts Thermostat Operation Temperature Operation Pressure adm. Differential Pressure Nominal Pressure Connection Manual override

cast-iron GG 25 SS/Ms 237.0120-xxx bis 120 °C up to 16 bar up to 16 bar PN 16 Flange DIN 2533 E

deliverable	e temperat	temperature ranges:								
20 - 30°C	37 - 47°C	57 - 66°C	71 - 79 °C	82 - 93 °C						
27 - 37°C	39 - 50°C	62 - 71°C	74 - 82 °C	85 - 96 °C						
32 - 41°C	43 - 54°C	66 - 74°C	77 - 85 °C	88 - 99 °C						
35 - 43°C	51 - 60°C	68 - 78°C	79 - 88 °C	93 - 103 °C						

AKO Temperature Regulators are suitable for the stabilization of Temperatures of media (e. g. water, oils, etc.) and are even applicable as dividing units or mixing valves. Depending on their construction they are distinguished by their low need of maintenance, particular operating convenience and resistance to pressure. A replacement of innerparts is possible on the spot without having to remove the regulating valve from the piping. A faulty assembly can be excluded. The temperature regulators could be assembled in each fitting position.

AKO Temperature Regulators are being equiped with easily replaceable internal wax-filled thermostats that absorb the temperaure of the medium surrounding them at the measurement point namely into expansion and thus a change in path or length (the valve stroke). AKO Temperature Regulators do not require any auxiliary energy. At rising temperature and on excess of the opening temperature, the tube slide is being lifted off of the valve seat and opening path A to C, with the path A to B locking simultaneously in the same ratio. The change is being performed in proportion to the change of temperature of the passing medium.

Manual Override: In order to meet the security demands of the classification societies for greater safety, the manual override was installed. It is not intended for setting the temperature when the regulating valve runs automatically. The manual resetting facility makes it possible to use the control valve as a manual change-over

valve. The taper can be brought into any desired position by means of an adjusting screw,

so that any operating temperature can be set by observing the thermometer.

h	order-no.	DN	D	g	b	h	Т	EL	К	L	pieces of thermostats	kg
	226.0121-040	40	150	88	18	102	172	178	110	4x18	1	13,0
	226.0121-050	50	165	102	20	150	165	225	125	4x18	1	17,0
	226.0121-065	65	185	122	20	165	146	254	145	4x18	2	25,0
	226.0121-080	80	200	138	22	171	138	267	160	8x18	2	28,0
	226.0121-100	100	220	158	24	217	155	403	180	8x18	4	43,0
	226.0121-125	125	250	188	26	241	212	489	210	8x18	6	68,0
30	226.0121-150	150	285	212	26	254	212	489	240	8x22	8	81,0